

# ACCESORIOS PARA MALLA CICLÓNICA

## Por Pieza

► Accesorios galvanizados para la correcta instalación de la malla ciclónica..

### ABRAZADERA DE ARRANQUE

mm	pulg	Calibre
33	1 3/8"	18
38	1 1/2"	18
42	1 5/8"	18
48	2"	18
60	2 1/2"	18
73	3"	18
89	3 1/2"	18
101	4"	18
114	4 1/2"	18



### KIT POSTE BASE

mm	pulg	Calibre
33	1 3/8"	16
38	1 1/2"	16
42	1 5/8"	16
48	2"	16
60	2 1/2"	16
73	3"	16
89	3 1/2"	16
101	4"	16
114	4 1/2"	16



### BISAGRA INDUSTRIAL

mm	Calibre
60 x 48	10
73 x 48	10




### COPE UNIVERSAL

mm	pulg
33	1 3/8"
38	1 1/2"
48	1 5/8"
48	2"
60	2 1/2"



### TAPÓN SIMPLE

mm	pulg
33	1 3/8"
38	1 1/2"
48	1 5/8"
48	2"
60	2 1/2"
73	3"



### TAPÓN OCHAVO

mm
48 x 42
60 x 42



### CONECTOR PARA MARCO



### TORNILLO COCHE CON TUERCA

pulg
5 / 16" x 11/4"



### COPE SIMPLE

mm
38
42



### COPE OREJA

mm
38
42



### TENSOR



### PASADOR



### CERROJO

cm
25
35



### TAPÓN MARCO

mm	pulg
42 x 42	1 1/8" x 1 5/8"
48 x 42	2" x 1 5/8"
60 x 42	2 1/2" x 1 5/8"
73 x 42	3" x 1 5/8"



### ESPADA SIMPLE

Calibre
18
20



### ESPADA INTEGRAL

pulg
1 5/8"
2 1/2"
2"
3"

